

# DISASSEMBLY INSTRUCTIONS

Remove the 4 screws, and gently separate the two halves of the cabinet. The complete P.C.B. assembly lifts out.

## 2.4 GHz ROOM-TO-ROOM

### A / V SENDER

#### DISASSEMBLY INSTRUCTIONS

(150-1971)

FAXBACK DOC # 25110

